













400*140mm

<p>Maintenance</p> <p>The ear cushions can be removed for cleaning or replacement</p>  <p>Accessories</p>  <p>Replacements & enhancements for the CB Series headsets:</p> <ol style="list-style-type: none">1) Foam microphone windscreen;2) Headset hook;3) Leatherette ear cushion;4) Clothing clip;	<p>Safety</p> <p>For your own safety, this product should only be used with CE and RoHS approved equipment. Using this headset with non approved equipment can void this products warranty.</p> 	<p><i>Freedom to Communicate</i></p>  <p>www.chatbit.co.nz</p> <p><small>© Go Wireless NZ Ltd 2015 All rights reserved</small></p>	 <p>CB80M/D User Manual</p> 
<p>6</p>	<p>7</p>		
<p>Headset Features</p> 	<p>Connecting Your Headset</p> <p>If your telephone has a headset port, insert the modular plug of the Quick Disconnect coil cord into the headset port:</p>  <p>WearingsYour Headset</p>  <p>To change ears, rotate the microphone boom over the headband to accommodate the left or right ear</p>	 <p>Place the headset receiver to your ear(s), if using a single ear headset you should set the T-bar above your other ear. Adjust the headband until it is comfortable, ideally ensuring there is virtually no pressure felt on the ear(s)</p> <p>To avoid low or distorted sound, and to provide clear and crisp telephone calls, the microphone should be positioned within 30-40mm of your mouth. The microphone boom arm will move in a variety of directions to ensure the best fit.</p>	 <p>Your new headset is supplied with a clothing clip to allow comfortable fitting of your headset without the cable getting caught or inadvertently pulled. The clothing clip should be fastened at a comfortable level, ensuring there is sufficient slack on the cable allowing free movement of your head without disturbing the headset position.</p> <p>Ear Cushion Removal</p> <p>Using both thumbs, remove the ear cushion by gently prying the earplate away from the groove on the receiver</p> 
<p>2</p>	<p>3</p>	<p>4</p>	<p>5</p>